

Download File PDF Kathrein User Manual

#Jenny



Finally I get this ebook, thanks for all these I can get now!

#Rio



Cool! I'am really happy

#Markus Jensen



I did not think that this would work, my best friend showed me this website, and it does! I get my most wanted eBook

#Hun Tsu



wtf this great ebook for free?!

#Che Salsa



My friends are so mad that they do not know how I have all the high quality ebook which they do not!

#Diego Butler




so many fake sites. this is the first one which worked! Many thanks

KATHREIN

Conversion


1. Unscreeing the cable from the LNB

- The LNB of the flat antenna BAS 63 has two outputs. The LNB of the flat antenna BAS 60 has only one antenna output.
- Loosen the two milled screws of the LNB cover. Remove the cover and place it aside.
 - Unscrew the cable from the LNB and pull it out of the cable support on the LNB.
 - Then screw the LNB cover again to the flat antenna. This will protect the LNB during the transport of the flat antenna.



2. Removal of the flat antenna


- Loosen the two hex. socket head screws of the mast bracket by means of an Allen key.
- Push the antenna cable somewhat backwards in order to be long enough for the removal of the flat antenna.
- Do not put the cable through the mast into the interior of the vehicle, it is impossible to pull the cable out again.
- Use both hands to remove the antenna from the joint of the mast. Place the antenna with its back pointing upwards on a solid non-slip support.



3. Removal of the mobile antenna support

The mobile antenna support of the flat antenna is fastened on the back of the antenna with 4 hex. socket head screws.

- Unscrew the 4 hex. socket head screws from the mobile antenna support. Keep the screws in a safe place because they will be needed again for fastening the new antenna support.
- Now place the mobile antenna support on the joint of the mast and tighten the mast bracket with the aid of an Allen key.



[Download PDF version of :](#)
Kathrein User Manual